








ALARM ICONS

PRODUCTS: IN CAB REPORTER (CR-2)

This document is a guide to the various alarm icons present on the Wheely-Safe In Cab Reporter (CR-2) and what triggers them



ICON	ALARM	TRIGGER
	Wheel Rim Temperature In Motion Mode – flashing red icon and bleeping for 5 minutes	The temperature of one of the vehicle wheel rims has exceeded 100°C.
	Maintenance Low Pressure Solid amber icon, no bleep Critical Low Pressure Flashing amber icon and bleeping for 5 minutes	The pressure of one of the vehicles tyres has decreased by 12% to 20%. The pressure of one of the vehicles tyres has decreased by more than 20%
	Tyre Temperature In Motion Mode – flashing red icon and bleeping for 5 minutes	The temperature of one of the TPMS sensors has exceeded 100°C
	Wheel Loss Motion Mode – flashing red icon and bleeping for 5 minutes	One of the vehicles' wheels is loose and at risk of detachment. Pull over immediately to inspect the wheels.
	Power Ignition On – icon flashes 5 times	The ignition is turned on.
	Diagnostics In development	