



WALKAROUND CHECKER WA-1

OPERATING INSTRUCTIONS



Use of the WalkAround Checker (WA-1):



- 1. Switching on the WA-1:**
 - Press the power button for two seconds; the lens will light up blue and a 'bleep' will sound. The lens will stay blue whilst the power is on.
 - If the WA-1 does not switch on, it needs to be charged with the micro-USB cable provided.
- 2. Reading a TPMS sensor:**
 - When switched on, hold the WA-1 over the TPMS sensor.
 - The WA-1 will 'bleep' and the lens will light up based on one of the pressure states identified below.
- 3. Understanding different types of TPMS sensor reading:**
 - Green: Tyre Pressure OK.
 - Amber: Maintenance alert - tyre pressure has decreased by between 15% and 25%.
 - Flashing Red with 3 bleeps: Tyre pressure has decreased by more than 25%.
- 4. How to read a wheel loss sensor (where fitted):**
 - When switched on, hold the WA-1 over the wheel loss sensor.
 - The WA-1 will 'bleep' and the lens will light up based on one of the below temperature states identified below.
- 5. Understanding the different types of wheel loss sensor reading (where applicable):**
 - Green with one 'bleep': wheel temperature OK (highest recorded temperature in the last 24 hours is below 100°C).
 - Flashing red with three 'bleeps': Critical high temperature (highest recorded temperature in the last 24 hours is 100°C or above).
- 6. Low battery indicator:**
 - If the battery of the WA-1 is low, after taking a pressure or temperature reading, the lens will flash blue three times after indicating the pressure or temperature reading.
- 7. Charging the WA-1:**
 - Attach the micro-USB cable provided to the WA-1.
 - Once connected to a power supply, the WA-1 will 'bleep' three times and the lens will flash blue every second during the charging process.
 - When charging is complete the WA-1 will 'bleep' and the lens will light blue until the micro-USB cable is removed.

TECHNICAL ASSISTANCE

If you have any queries regarding the installation or use of this product please contact Wheely-Safe directly:

info@wheely-safe.co.uk

IMPORTANT INFORMATION

It is imperative that all staff/personnel be aware that even with the Wheely-Safe system fitted, normal tyre and wheel inspection, removal, maintenance and walkaround procedures/policies must still be adhered to.

No liability can be offered by Wheely-Safe Ltd for any loss or damages incurred as a result of the devices being fitted.

For further technical information, please refer to the product's technical specification.

WARRANTY

All Wheely-Safe products are covered by a comprehensive 12-month warranty, beginning from the date of purchase.

We encourage you to ensure that all parts are fitted by a competent person in accordance with manufacturer specifications. Wheely-Safe Ltd cannot be held liable for any damage caused by the fitting of a Wheely-Safe component.

Please ensure that you have read your warranty conditions before attempting to install the Wheely-Safe system, or repair an item on your vehicle. Wheely-Safe Ltd cannot be held responsible if an item is damaged or your warranty is voided. Please be aware that some manufacturer guarantees may be on the condition that you use a qualified technician for the installation of any ancillary equipment.

PRODUCT DISCLAIMER

The Wheely-Safe system is designed as a driver assistance device and should not be used as a substitute for regular manual wheel and tyre safety checks.

- Neither the seller, nor the manufacturer, will be liable for any loss, damage or injury, directly or indirectly arising from the use or inability to determine the use of this product.
- Before fitting, the user shall determine the suitability of the product for its intended use, and the user shall assume all responsibility and risk in connection herewith.
- The driver/operator is always responsible for the condition of the wheels/tyres on their vehicle and regular pre-use visual checks are essential to stay wheel and tyre safe.
- All tyres/wheels, including pressures, should be checked before any journey, when tyres are in their cold state, using an accurate tyre pressure gauge.
- When checking pressures, it is recommended all tyres receive a thorough inspection, checking tread depths and looking for any tyre damage or uneven wear. Wheel nuts, studs and rims should also be checked to ensure they are damage free and in a suitable condition prior to commencing the journey.

Published product details, specifications and suitability information is the best available at the time of publication. Wheely-Safe Ltd shall not be held responsible for the accuracy of any advice given regarding the suitability (or otherwise) of any part(s).

